


POINT-OF-SALE DISPLAY INSTRUCTIONS

1. Remove all items from their packaging: acrylic Point-of-Sale Display and acrylic signage holder.
2. Use the suggested layouts below to place product in the display.
3. Slide acrylic signage holder into tabs on the back of the Point-of-Sale Display.
4. Insert signage into the holder.

Note: There is room to keep back stock of extra product underneath the top shelf.



Signage Orientation in Holder



Back of Signage

SUGGESTED PRODUCT ARRANGEMENTS

